

2014 RAM 1500 Carputer — Power · Fuse · Control Wiring (rev 3.10)

LINE THICKNESS = wire gauge (THICKER = heavier wire / more current). RED = positive (fused) BLUE = negative (NEVER fused) GREEN = the one chassis bond PURPLE dashed = control / trigger (Cat5 / 22 AWG)
 Gauge→thickness: 2 AWG ■ 4 AWG ■ 6 AWG ■ 8 AWG ■ 10-14 AWG ■ 16-22 AWG
 Every battery fused at its + terminal · Trunk fused BOTH ends · High-current returns to the - bus bar, never chassis

